
JMQ03

00



3.1 JMQ03

1		PSt 00	00
2	55	PSt55	/ 55
3		S-codE	
4	111111	S111111	6 1
5		K-code1	K
6	123456	K123456	123456
7		K-code2	K
8	123456	K 789	789
9		LOCK	
		PASS	"PASS" "Err16"
10			LoSE

5		K-codE1	K	
6	123456	K123456	123456	
7		K-codE2	K	
8	123456	K -co789	789	
9		CLEAR		"PASS"
		PASS		"Err16"
			LoSE	
10				